



OPERATION

1 INTERIOR OF BLOCK TO BE HOLLOW

GENERAL NOTES:

-SPECTIS ADHESIVE MUST BE USED ON ALL BEDDING/BUTT JOINTS

°SPECTIS MOULDERS INC.



P.O. BOX 970 100 CEDAR DRIVE NIVERVILLE, MANITOBA CANADA ROA 1E0 PHONE: 204-388-6700 PHONE: 800-685-9981 FAX: 204-388-6710 BOX 479 PEMBINA, NORTH DAKOTA 58271-0479 U.S.A

GENERAL NOTES:

ALL PRODUCTS ARE DRAWN FOR PRESENTATION PURPOSSES, ONLY IMAGE MAY VARY SLIGHTLY FROM ACTURAL PART

2. DRAWING INTENT IS TO INDICATE GENERAL ARRANGEMENT, DESIGN AND INTENT OF WORK IS PARTLY DIAGRAMATIC.

CUSTOMER NAME:			PART:
STANDARD PRODUCT			BL 2909L 7-12
REFERENCE:			SHEET:
BLOCK			1 OF 1
DRAWN BY:	DATE:	SCALE:	REV:
JE	07/01/19	½" = 1"	