



1 OPERATION
INTERIOR OF BLOCK TO BE HOLLOW

GENERAL NOTES:
-SPECTIS ADHESIVE MUST BE USED
ON ALL BEDDING/BUTT JOINTS



1. All rights reserved. This document may not be used or duplicate without prior consent.

SPECTIS MOULDERS INC.

P.O. BOX 970
100 CEDAR DRIVE
NIVERVILLE, MANITOBA
CANADA R0A 1E0

PHONE: 204-388-6700
PHONE: 800-685-9981
FAX: 204-388-6710

BOX 479
PEMBINA,
NORTH DAKOTA
58271-0479
U.S.A

GENERAL NOTES:
1. ALL PRODUCTS ARE DRAWN FOR PRESENTATION PURPOSES, ONLY IMAGE MAY VARY SLIGHTLY FROM ACTUAL PART
2. DRAWING INTENT IS TO INDICATE GENERAL ARRANGEMENT, DESIGN AND INTENT OF WORK IS PARTLY DIAGRAMATIC.
3. SPECTIS RESERVES THE RIGHT TO CHANGE ANY PRODUCT DESIGN WITHOUT NOTICE.

CUSTOMER NAME:			PART:
STANDARD PRODUCT			BL2909R 6-12
REFERENCE:			SHEET:
BLOCK			1 OF 1
DRAWN BY:	DATE:	SCALE:	REV:
JE	07/01/19	1/4" = 1"	